


CHRISTIE

Operations Counter Installation Instructions



Description

The Operation Counter Module is designed to be used with Christie CC2 series cooktop to log the number of operations and to provide a record of usage.

The Operations Counter Module only records the cooking cycle of the cooktop and ignores any other input, making it proof against tampering of the cooktop start-stop cycle and consequent faulty data. It can only be reset by removing the front cover with a screwdriver, preventing accidental or unauthorised resetting.

The module is supplied in a rugged, polycarbonate weather-proof enclosure and comes with a universal mounting bracket. The module is self-powered, has a 10-year battery life and requires no maintenance apart from external cleaning. Do not use abrasive cleaners on the clear front cover of the module.

Safety instructions

- Wear personal protective equipment, e.g., safety glasses, gloves etc. at all times
- Any variation from the original Product Specification, including the use of different components, may result in improper operation and reduced functionality
- The unit must be installed, operated, and maintained as per the Manufacturer's instructions

Tools required

- Adjustable spanner
- Long nose pliers
- No.2 Phillips screwdriver
- Large flat blade screwdriver

Installation

STEP 1

Remove the cooktop.

1. Gain access to the underside of the cooktop
2. Turn off mains power at the 15Amp power outlet
3. Disconnect 15Amp plug from the power outlet
4. Locate, undo and remove 1 x wing-nut and 1 x flat washer from the right hand hold-down bracket
5. Repeat step 4 for the left hand hold down bracket
6. With assistance, lift the cooktop up from the cabinet, turn upside down and place on the hotplate surface
7. Remove 6 x retaining screws from control box lid and remove lid

NOTE: Be careful not to damage the moisture seal with in the control box lid through the cable gland.

Installation

STEP 2

Install the counter lead into the cable gland

1. Cut the cable-tie securing the thermistor and start/stop button cables
2. Undo cable gland locking nut and slide back from control box
3. Locate 2-pin connector on the operations counter and install through the cable gland locking nut
4. Install connector ontop of the existing cables and push through the cable gland




Installation

STEP 3

Install the counter lead through the cable gland


1. Using a flat blade screwdriver, gently push the connector through the cable gland
2. Long nose pliers can also be used to pull through the connector



STEP 4

Install the counter onto the main control board

1. Locate the 2-pin connector location on the main control board marked "COUNT"
2. Install 2-pin connector onto the main control board in the "COUNT"



Installation

STEP 5

Reinstall control box lid and cable gland

1. Replace control box lid and reinstall 6 x retaining screws
2. Reinstall and tighten cable gland lock nut
3. Instal 1 x cable tie to secure operation counter cable to existing cables at the end of the cable gland



STEP 6

Reinstall cooktop

1. With assistance, lift up cooktop, turn-over and reinstall into cabinet
2. Reinstall 1 x flat washer and 1 x wingnut onto each hold down clamp and tighten


STEP 7

Mount the operation center module

1. If using the adhesive strips, thoroughly clean the mounting surface using the alcohol wipe supplied with the module
2. Peel off the protective paper from the adhesive and firmly press the module into place

To Reset the Module

1. Remove the front clear cover from the housing by undoing the four retaining screws.
2. Press the 'RS' button on the counter
3. Replace the Cover - Ensure the inside of the clear cover is clean before reattaching to the using.
4. Tighten the four screws - Do not over-tighten the screws to avoid cracking the clear cover



Installation

**WARNING:**

- Use only non-toxic cleaning product with a neutral pH between 6 and 9
- Caustic cleaning product may leave a toxic residue and corrode important components
- Do not use sharp objects, brushes, or abrasives

To ensure the lasting safety of your Christie operation counter module, we recommend that it is cleaned monthly.

- Spray the aluminum interior and stainless steel exterior with a mild detergent or pH-neutral, bio-degradable degreaser
- Allow to stand for at least 5 minutes
- Rinse with water then dry with a clean cloth or paper towel
- Repeat if necessary until the product is clean

For technical support, repairs, and maintenance enquiries please contact us on **+61 03 9708 2999** or **support@dachristie.com**.